

# **SONDRE STROMFJORD (BGSF)**

## **✈ IFR TAKE-OFF MINIMUMS AND DEPARTURE PROCEDURES**

### **Civil Airports and Selected Military Airports**

CIVIL USERS: FAR 91 prescribes take-off rules and establishes take-off minimums for certain operators as follows: (1) Aircraft having two engines or less - one statute mile. (2) Aircraft having more than two engines - one-half statute mile.

Airports with IFR take-off minimums other than standard are listed below. Departure procedures and/or ceiling visibility minimums are established to assist all pilots conducting IFR flight in avoiding obstacles during climb to the minimum enroute altitude. Take-off minimums and departures apply to all runways unless otherwise specified. Altitudes, unless otherwise indicated, are minimum altitudes in feet MSL.

MILITARY USERS: Special IFR departure procedures not published as Standard Instrument Departure (SIDs) and civil take-off minima are included below and are established to assist pilots in obstacle avoidance. Refer to appropriate service directives for take-off minimums.

<b>AIRPORT NAME</b>	<b>TAKE-OFF MINIMUMS</b>
---------------------	--------------------------

<b>SONDRE STROMFJORD (BGSF)</b>	
---------------------------------	--

Kangerlussuaq, Greenland	
--------------------------	--

Diverse departure not authorized.	
-----------------------------------	--