CJN2F, KAMPO2F, NVS2F, SIE1K DEPARTURE



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 23: Climb direct until reaching 2500. Turn left, (Max Turn CAT AB 160 KIAS, CAT C 185 KIAS), to follow BRA VOR/DME R-114 direct to cross ELVIR at or above 5000. Thence....

CASTERJON TWO FOXTROT DEPARTURE (CJN2F): Turn left to follow CJN VOR/DME R-273 direct to cross CJN between FL80 and FL190.

KAMPO TWO FOXTROT DEPARTURE (KAMPO2F): Turn right direct to PDT VOR/DME (Max Turn 185 KIAS). Proceed on PDT R-230 direct to cross KAMPO between FL90 and FL190. Note: Maintain FL90 except ATC clearance.

NAVAS TWO FOXTROT DEPARTURE (NVS2F): Turn right direct to PDT VOR/DME (Max Turn 185 KIAS). Proceed on PDT R-265 direct to GE NDB. Turn right to follow NVS VOR/DME R-121 direct to cross NVS between FL80 and FL190. Note: Maintain FL90 except ATC clearance.

SOMOSIERRA ONE KILO DEPARTURE (SIE1K): Turn right direct to PDT VOR/DME (Max Turn 185 KIAS). Proceed on PDT R-292 direct to cross ARGUS between 5000 and FL120. Proceed on NVS VOR/DME R-100 up to 21.5 DME. Turn right to intercept and follow SIE VOR/DME R-194 direct to cross 34.5 DME at or above FL145, direct cross SIE at or below FL190.

Effective 3 AUG 2006 - 31 AUG 2006