



▼

DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 09: Max 190 KIAS until OL VOR/DME. Climb on heading to 3000, at 1000 turn left to intercept and follow TSU VOR R-078. On crossing OL VOR/DME R-321, turn right on mag tr 133° to intercept and follow OL R-343 to OL. At OL turn right on mag tr 203°, crossing RBT R-093, turn right on RBT R-101 (mag tr 281°), thence...

EVX 1U (EVREUX): (Svcbl to ABBEVILLE [ABB VOR], FL less than 130) At RBT flw R-281 to 17.5 DME, turn right to EVX R-150 (mag tr 330°) inbd EVX.

EVX 1W (EVREUX): At RBT, flw RBT R-288 (mag tr 288°). At 20.1 DME turn right on EVX R-150 (mag tr 330°) inbd EVX.

LGL 1U (L'AIGLE): At RBT, flw LGL VOR R-101 (mag tr 281°) to LGL.

LGL 1W (L'AIGLE): At RBT flw R-288 (mag tr 288°). At 20.1 DME, turn left to LGL R-096 (mag tr 276°) to LGL.