

RWY 27L/R DEPARTURES

[USAF] SL-1870 (GM)

BERLIN, GERMANY



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 27L/R:

BKD 5Q: Climb to 5000 direct DBR NDB. Turn left on track 250° to intercept TOF VOR/DME R-256 to TOF 25 DME. Turn right track 336° to TUBRI, turn left track 299° to BKD VOR/DME.

FWE 3Q: Climb to 4000 direct to DBR NDB. Turn left track 250° to TOF VOR/DME 9 DME. Turn left on FWE VOR/DME R-263 to FWE VOR/DME. Turn at TOF 9 DME limited to 230 KIAS.

GENTI 1Q: Climb to 4000 direct DBR NDB. Turn left on track 250° to intercept TOF VOR/DME R-256 to GENTI.

GILAS 7Q: Climb to 5000 direct to DBR NDB. Turn left track 250° to TOF VOR/DME 9 DME. Turn left on FWE VOR/DME R-263 to FWE VOR/DME. Turn left on FWE R-045 to GILAS. Turn at TOF 9 DME limited to 230 KIAS.

RAKIT 3Q: Climb to 5000 direct to DBR NDB. Turn left track 250° to TOF VOR/DME 9 DME. Turn left on FWE VOR/DME R-263 to FWE 15 DME. Turn left on KLF VOR/DME R-017 to KLF 49 DME. Turn left on FWE VOR/DME R-348 to RAKIT. Turn at TOF 9 DME limited to 230 KIAS.

SUI 8Q: Climb to 5000 direct to DBR NDB. Turn left track 250° to TOF VOR/DME 9 DME. Turn left on FWE VOR/DME R-263 to FWE 8 DME. Turn right on SUI VOR/DME R-271 to SUI. Turn at TOF 9 DME limited to 230 KIAS.

TUVAK 3Q: Climb to 5000 direct to DBR NDB. Turn left track 250° to TOF VOR/DME 9 DME. Turn left on FWE VOR/DME R-263 to FWE 8 DME. Turn right on SUI VOR/DME R-271 to TUVAK. Turn at TOF 9 DME limited to 230 KIAS.

RWY 27L/R DEPARTURES

BERLIN, GERMANY

TEMPELHOF (EDDI)

Effective 3 AUG 2006 - 31 AUG 2006