



## DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 08: Climb on track 082° then at 3 DME/2 NM turn left to intercept RMS R-060 direct BOLKI. Climb and maintain 5000. (Non-TACAN equipped aircraft expect further clearance prior to BOLKI or passing 4000 or as instructed by ATC)

TAKE-OFF RWY 09: Climb on track 087° then at 3 DME/2 NM turn left to intercept RMS R-060 direct BOLKI. Climb and maintain 5000. (Non-TACAN equipped aircraft expect further clearance prior to BOLKI or passing 4000 or as instructed by ATC)

BOLKI 2E TRANSITION (Eastbound routes): For flights via NEKOM, from BOLKI proceed via Q762, Z12 to NEKOM.

BOLKI 2L TRANSITION (Northwestbound routes): For flights via LIMGO, from BOLKI proceed via Q762, W718, Z729, Q760, Q763 to LIMGO.

BOLKI 2N TRANSITION (Northbound routes): For flights via OLIVI, from BOLKI proceed via Q762 to OLIVI.

BOLKI 2S TRANSITION (Southbound routes): For flights via BADLI, from BOLKI proceed via Q762 to BADLI.

BOLKI 2W TRANSITION (Westbound routes): For flights via SBN, from BOLKI proceed via Q762, W718 to SBN NDB.

Must file Flight Plan with transition,  
not plannable without transition.