



TAKE-OFF RWY 26: Climb on track 275°. At 2.2 DME turn right to track 300° to intercept RMS R-281 outbound to TOLEY. Non-TACAN equipped aircraft turn right on track 281° direct TOLEY. All aircraft climb and maintain 5000 or as instructed by ATC, then . . .

TAKE-OFF RWY 27: Climb on track 269°. At 2.2 DME turn right to track 300° to intercept RMS R-281 outbound to TOLEY. Non-TACAN equipped aircraft turn right on track 281° direct TOLEY. All aircraft climb and maintain 5000 or as instructed by ATC, then . . .

TOLEY 2E TRANSITION (Eastbound routes): For flights via NEKOM, from TOLEY proceed via Q760, Z729, W718, to NEKOM.

(Continued on next page)