



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 07: Climb to 5000. Climb on track track 073° to SG NDB (SGD 4.6 DME) or 3500 whichever is later, then turn right to TGO VORTAC, thence . . .

ROTWE3H: proceed via TGO R-254 to ROTWE. Via NATOR only for jet aircraft.

SUL7H: proceed via TGO R-239 to SUL VOR.

TAKE-OFF RWY 25: Climb to 5000. Climb on track track 253° to SY NDB (SGD 4.5 DME), thence . . .

ROTWE2B: track 253° to SGD 15 DME, then turn left via LBU VOR/DME R-227 to ROTWE. Via NATOR only for jet aircraft.

SUL1B: turn left to track 199° to intercept SUL VOR R-059 to SUL VOR.