

BASUM 8B, DLE 4H, LBE 6B, IDEKO 1B, WSR 6B DEPARTURE

HAMBURG, GERMANY

ATIS ★ 123.125

GND CON

121.8

HAMBURG TOWER

126.85 278.45

HAMBURG DIRECTOR

118.2 242.4

BREMER RADAR

124.225 242.4

134.25

[USA] SL-2034 (GM)

ELBE
115.1 LBE
Chan 98
L-5

ALSTER
ALF
Chan 105

Remain on twr frequency until passing
2000, then contact BREMER RADAR 134.25.

WESER
112.9 WSR
L-5

WSR 6B:
Mandatory for flights
continuing via
G10/UG10 EEL.

OSNABRUCK
114.3 OSN
L-5

BASUM

L-5

NIENBURG
116.5 NIE
L-5


BASUM 8B:
Mandatory for flights continuing via
R15/UM170 OSN.

DLE4H:
1. Only for flights requesting FL 250 or above.
2. Cross LBE 40 DME at or above FL 160 due to
airspace structure.

IDEKO 1B:
Mandatory for flights continuing via N850 and
Y900/TIMEN/UL126.

HAMBURG
113.1 HAM
Chan 78

HAMBURG WEST
350.5 FU
L-5



LEINE
115.2 DLE
Chan 99
L-5

TA 5000

DEPARTURE ROUTE DESCRIPTION

Initial clearance limit 5000. Remain on twr frequency until passing 2000, then contact Bremen Radar.

TAKE-OFF RWY 23: Climb direct FU NDB (ALF 5.5 DME), thence...

BASUM8B: Track 230° from FU to intercept HAM VORTAC R-236 to HAM 38 DME, then turn left on LBE R-208 to BASUM.

DLE4H: (Only for flights at FL250 or above) Track 230° from FU to ALF 20 DME, then turn left on LBE R-187 to IDEKO (LBE 40 DME), then turn left on DLE VOR/DME R-340 to DLE. Cross LBE 40 DME at or above FL160.

LBE6B: Turn right on LBE VOR/DME R-122 to LBE.

IDEKO1B: On track 230° to ALF 20 DME, then turn left on LBE VOR/DME R-187 to IDEKO.

WSR6B: Turn right on WSR VOR R-069 to WSR.

BASUM 8B, DLE 4H, LBE 6B, IDEKO 1B, WSR 6B DEPARTURE

HAMBURG, GERMANY

HAMBURG (EDDH)

Effective 3 AUG 2006 - 31 AUG 2006