



DEPARTURE ROUTE DESCRIPTION

SB 21: TAKE-OFF RWY 03: Climb on track 031°, cross BUE 5 DME at 4000. Turn right on track 228° to intercept BUE R-205/10 DME. Thence. . .

SB 1: TAKE-OFF RWY 21: Climb and turn left to intercept BUE R-205 and proceed direct to 10 DME. Cross BUE R-205/4 DME at 3000'. Thence...

SB 1-21: Cross BUE R-205/10 DME at 4000, BUE 29 DME at or above FL70. At BUE R-205/34 DME turn left to intercept SPA R-178. Continue to TRANSITION.

SB 1-21 H/L: Cross SPA R-178/28 DME at or above FL70. Cross SPA R-178/34 DME at or below FL120. At SPA R-178/34 DME turn left track 110°, thence . . .

SB 1-21 Low: Cross PIREK at or below FL120, cross GERKU at FL170.

SB 1-21 High: Cross PIREK at or above FL250.

SB 1V-21V: For VMC ON TOP. Cross SPA R-178/25 DME at or below FL95.

TOLEY: Maintain FL70, at BUE R-205/34 DME turn left to intercept RMS R-283 and proceed direct TOLEY (RMS R-283/23 DME). Cross TOLEY at or below FL100.