



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 05: Climb to 5000 tracking 050° to SPA TACAN 10 DME Arc, arc right and cross SPA R-078 at or above 5000, at SPA R-133 track 230° and intercept SPA R-178 at 13 DME outbound then ...

TAKE-OFF RWY 23: At DER (.9 DME) or 400' AGL, whichever occurs last, climbing left turn to 5000 tracking 200°. If able, avoid overflight of village 1.2 NM from DER. At SPA TACAN 1.5 DME turn left tracking 150° and intercept SPA R-178 at 13 DME outbound then ...

AD22H TRANSITION: At SPA 34 DME turn left tracking 110° to cross PIREK at or above FL250.

AD22L TRANSITION: At SPA 34 DME turn left tracking 110° to cross GERKU at FL170.

AD22T TRANSITION: At SPA 23 DME turn left to intercept RMS TACAN R-283 to TOLEY, cross TOLEY at or below FL100.