

NOMBO3S, RATIM1S, SULUS3S DEPARTURE

[USAF] SHL-1736 (GM) FRANKFURT, GERMANY

DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 18: Climb and maintain 4000. Climb on rwy track to 800 or RID 12 DME, whichever is later. Then turn left on track 118°. Cross FFM R-201 at or above 2500.
Thence . . .

NOMBO3S: To KNG NDB. After KNG turn right on track 103° to AKONI. Intercept FFM R-130 to HAREM. Turn right on track 148° to LAMPU. Turn left on track 134° to NOMBO INT.

RATIM1S: To KNG NDB. After KNG turn right on track 103° to RATIM via AKONI.

SULUS3S: To KNG NDB. After KNG turn right on track 103° to GIBSA via AKONI and RATIM. Turn left track 074° to WUR VOR. Depart WUR left turn on track 054° to SULUS.