



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 26: Climb on track 262°. At 2 DME turn right to intercept RMS R-270 to 12 DME, then turn right to intercept the RMS R-272 direct MAPIG. Non-TACAN equipped aircraft turn right on track 270° to 12 DME, then turn right direct MAPIG. Climb and maintain 5000 or as instructed by ATC. Expect further clearance prior to MAPIG or passing 3400 then ...

TAKE-OFF RWY 27: Climb on track 267°. At 2 DME turn right to intercept RMS R-270 to 12 DME, then turn right to intercept the RMS R-272 direct MAPIG. Non-TACAN equipped aircraft turn right on track 270° to 12 DME, then turn right direct MAPIG. Climb and maintain 5000 or as instructed by ATC. Expect further clearance prior to MAPIG or passing 3400 then . . .

MAPIG 1E TRANSITION (Eastbound routes): For flights via NEKOM, from MAPIG proceed via Q760, Z729, W718, to NEKOM.

(Continued on next page)