



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RUNWAY 21: Climb on 200° to 2 DME, right turn to 040° within 6 DME of SLN TACAN; climbing not above 5000 and intercept R-350 SLN TACAN. At 7 DME recommence climb out R-350, right climbing turn at 15 DME, complete within 22 NM to intercept R-020 SLN TACAN inbound; cross 15 DME at FL 190 or below; report at 5 DME and if not at assigned altitude or cleared to climb overhead SLN TACAN, shuttle right between 10 DME and 5 DME on R-020.

ELEV 405

TA 5000



AL 1 HI LEVEL SID RWY 21