



DEPARTURE ROUTE DESCRIPTION

(Continued)

TAKE-OFF RWY 09: Climb via HG NDB, thence

GEVLI TWO (GEVLI 2A): to FLR NDB. At FLR turn right onto FLR brg 250°. Intercept and follow TRM R-221 to GEVLI.

GEVLI TWO X-RAY (GEVLI 2X): towards FLR. At HG or at 2500, whichever is the later, turn left to TRM, intercept and follow TRM R-221 to GEVLI.

KOTEX TWO ALFA (KOTEX 2A): to FLR NDB. At FLR turn right onto FLR brg 250°. Intercept and follow TRM R-196 to KOTEX.

KOTEX TWO X-RAY (KOTEX 2X): towards FLR. At HG or at 2500, whichever is later, turn left to TRM, intercept and follow TRM R-196 to KOTEX.

NORPO TWO ALFA (NORPO 2A): to R NDB. At FLR turn right onto FLR brg 185° to NORPO.

OGNAN TWO ALFA (OGNAN 2A): to FLR NDB. At FLR turn left onto FLR brg 009° and proceed to OGNAN.

OGNAN TWO X-RAY (OGNAN 2X): towards FLR NDB. At FLR or at 2500, whichever is later, turn left to intercept HG brg 030° and proceed to RINLO. After RINLO turn left onto FLR brg 009° to OGNAN.

ROSEB TWO ALFA (ROSEB 2A): towards FLR NDB. At Hg or at 2500, whichever is later, turn left to TRM, intercept and proceed on TRM R-254 to ROSEB.