

## HIWAY-TWO DEPARTURE (HIWAY2•LEEE)

LAS VEGAS, NEVADA

ATIS  
270.1  
CLNC DEL  
120.9 289.4  
GND CON  
121.8 275.8  
NELLIS TOWER  
132.55 327.0  
NELLIS CONTROL  
119.35 254.4  
NELLIS DEP CON  
135.1 385.4

SHL-227 [USAF]

Rwy	Knots	60	120	180	240	300	360
*3 L/R (a)	V/V(fpm)	360	720	1080	1440	1800	2160
†3 L/R (b)	V/V(fpm)	630	1260	1890	2520	3150	3780
*21 L/R (c)	V/V(fpm)	420	840	1260	1680	2100	2520
†21 L/R (d)	V/V(fpm)	490	980	1470	1960	2450	2940

\* Minimum † ATC Climb Rate


(a) to 10,400

(b) to 7500

(c) to 14,000

(d) to 14,000

- ① 0.45 NM from Rwy 21R
- ② 12.2 NM from Rwy 21R
- ③ 17.4 NM from Rwy 21R
- ④ 0.8 NM from Rwy 03L
- ⑤ 5.7 NM from Rwy 03L
- ⑥ 15.7 NM from Rwy 03L
- ⑦ 25.7 NM from Rwy 21R
- ⑧ 29.3 NM from Rwy 21R



## DEPARTURE ROUTE DESCRIPTION

**TAKE-OFF RWY 3L/R:** Track Rwy heading to intercept and proceed outbound on the LSV R-025, cross LSV R-025/9 DME at or above 7500. Continue outbound LSV R-025 to intercept the 15 DME arc, arc west until LSV R-265/15 DME. Cross the LSV R-350 at or above 10,400. Proceed outbound on the LSV R-265 until 25 DME, cross the R-265/25 DME LEEEEE INT at or above 14,000. Then via transition.

**TAKE-OFF RWY 21L/R:** Track RWY heading until LSV 2.5 DME, then turn right heading 300° cross LSV R-253 between 5000 and 6000, intercept and proceed outbound on the LSV R-265 until 25 DME, cross LSV R-265/25 DME at or above 14,000. Then via transition.

**BEATTY TRANSITION:** (BTY) Turn right at the LSV R-265/25 DME direct BTY via the BTY R-100.

**CESAR TRANSITION:** Turn right at the LSV R-265/25 DME to proceed inbound on the BTY R-100 until BTY R-100/26 (LSV R-275/64), cross the BTY R-100/26 DME between 16,000/FL230, then turn right heading 305° to the BTY R-066/13 DME thence direct CESAR (LSV R-288/85) direct assigned range.

## HIWAY-TWO DEPARTURE (HIWAY2•LEEE)

LAS VEGAS, NEVADA

NELLIS AFB (KLSV)

Effective 3 AUG 2006 - 31 AUG 2006